



8012-2-C
through
8012-7-C

Parts Reference

| Ref. No. | Description | Ref. No. | Description | Ref. No. | Description |
|----------|---------------------------|----------|-----------------------|----------|---------------------|
| 1 | Cover Screw | 25 | Washer | 48 | Weight |
| 2 | Emblem | 26 | Retaining Clip | 49 | Flexure Bearing |
| 3 | Cover | 27 | Clevis Pin | 50 | Flexure Bearing |
| 4 | Mounting Screw | 28 | Clevis | 52 | Biasing Spring |
| 5 | Magnet S/A | 29 | Cap Screw | 53 | Machine Screw |
| 6 | Adjusting Screw | 30 | Serial Plate | 54 | Cap |
| 7 | Nut | 31 | Lever (Stroke Adj.) | 55 | Diaphragm S/A |
| 8 | Spring (Force Balance) | 32 | Stroke Lever | 56 | Bellofram Plate S/A |
| 9 | Screw | 33 | Spring (Stroke Lever) | 57 | Gasket |
| 10 | Spring Lever | 34 | Back Lever | 58 | Spring |
| 11 | Locking Nut | 35 | Back Lever Adapter | 59 | Metering Tube S/A |
| 12 | Adjusting Screw | 36 | Snap Ring | 65 | O-Ring |
| 14 | Case | 37 | Screw | 66 | Relay Body |
| 15 | Terminal Board S/A | 39 | Spring Bracket | 67 | Relay Plug |
| 16 | Nozzle | 40 | Coil S/A | 68 | Spring |
| 18 | Adapter (Flame Arrestor) | 41 | Beam | 69 | Holding Screw |
| 19 | Gasket | 42 | Screw | 70 | Sleeve Bearing |
| 20 | Relay | 43 | Locknut | 71 | Bearing Post |
| 21 | Mounting Screw (Relay) | 44 | Machine Screw | 72 | Bearing Post |
| 22 | Mounting Bracket | 45 | Machine Screw | 73 | Groove Pin |
| 23 | Screw | 46 | Flapper | 74 | Flame Arrestor |
| 24 | Cover Plate (Stroke Adj.) | | | 75 | Nipple |